

SELECTION CHART

Pistol Type



Push-Start Type




Lever-Start Type




Angle-Head Type




TORQUE-CONTROL TYPE



CUSHION CLUTCH TYPE



IMPACT TYPE



DIRECT DRIVE TYPE

